

ASSEMBLY INSTRUCTIONS

1 of 3

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.


NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed : Screwdriver & Hammer (not provided).


PART LIST		
ITEM	DESCRIPTION	QTY
A	SEAT	1 PC
B	BACK	1 PC
C	SUPPORT WOOD	1 PC
D	ARM	2 PCS

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBB BOLT M8 x 50mm 	11 PCS
2	M8 FLAT WASHER 	3 PCS
3	M8 SPRING WASHER 	11 PCS
4	WOOD DOWEL M10 x 40mm 	4 PCS
5	WOOD BUTTON DIA 18.5mm 	6 PCS
6	M5 ALLEN KEY (BALL SHAPE) 	1 PC

STEP 1



STEP 2





ASSEMBLY INSTRUCTIONS


2 of 3

STEP 3


Step 3.1



Step 3.2




Step 3.3





STEP 4


Step 4.1



Step 4.2



Step 4.3



ASSEMBLY INSTRUCTIONS

3 of 3

STEP 5

