

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS :


1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.
Tool needed : Screwdriver & Rubber Mallet (not provided).


PART LIST		
ITEM	DESCRIPTION	QTY
A	CHAIR LEG (L)	1 PC
B	CHAIR LEG (R)	1 PC
C	SUPPORT RAIL	2 PCS
D	CHAIR	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC Bolt M6 x 45mm 	4 PCS
2	WOOD SCREW M4 x 45mm 	6 PCS
3	WOOD DOWEL M8 x 30mm 	8 PCS
4	M6 SPRING WASHER 	4 PCS
5	M4 ALLEN KEY (BALL SHAPE) 	1 PC

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

2 OF 3

STEP 3



STEP 4




ASSEMBLY INSTRUCTIONS

3 OF 3

STEP 5

Note : Follow the line drawing to assemble the chair leg.



STEP 6

