

Read this instruction carefully. See hardware and furniture part list for guidance.
Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.
Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.


2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST			
ITEM	DESCRIPTION	QTY	
A	BENCH	1 PC	
B	LEG	4 PCS	

PART LIST			
ITEM	DESCRIPTION	QTY	
1	JCBC Bolt M6 x 40mm	8 PCS	
2	M6 FLAT WASHER	8 PCS	
3	M4 Allen Key	1 PC	

STEP 1



STEP 2

